

Optimize audio quality for Konftel with Skype

Step 1

Start Skype and go to “Tools” > “Options”



Step 2

Go to “Audio settings” and **deselect** “Automatically adjust microphone settings” and “Automatically adjust speaker settings”.

Check the microphone volume and drag the slider if you think that the level is to low or high.

